



RC 4400 - RC 4401 - RC 4402

Spare Parts



Position	Description	Reference
1	Complete Motor Block C	R0632000
2	BowlC	R0633400
3	Impeller C	R0633200
4	Flow OutletC	R0633500
5	Exhaust Valve C (Set of 3)	R0633300
6	Motor block Shaft pin Ø4 (Set of 5)	R0657900
7	Handle Shaft C	R0633600
8	Complete free gear box C RAL9022	R0632200
9	Complete gear box C RAL9022	R0632300
10	Track C Z (Set of 2)	R0633900
11	Bottom plate	R0633800
12	body A Blue C	R0633700
13	Brush scrubber C RAL9022 Z (Set of 2)	R0633100
14	Complete filter 100 C Z	R0632600
15	Complete filter 200 C Z	R0632601
16	Complete filter 60 C Z	R0632602
17	Complete cover C A-0	R0632400
18	Complete Handle C Blue Z	R0631900
19	Complete Floating cable C 18 m	R0632101
20	Connector 3PTS body	R0634100
21	Floating cable CZ	R0634200
22	Caddy Handle	R0565000
23	Caddy wheels (*2)	R0565100
24	Trolley tube C	R0634400
25	Complete lower partTrolley C	R0632800
26	Trolley C Accessories	R0632900
27	Screws 4*12 mm (x5)	R0516700
28	Screw 4*16mm (Set of 5)	R0608500
29	Control box Type 1 C	R0633000
30	Polyester Brushes (*2)	R0697600
31	Complete Brush roller C + 2 keys	R0722400
32	Transport Trolley Vortex	R0639500
-	Kit for slippery surfaces *2	R0718600